

Gebrauchshinweise – Rauchmelder Pyrex



Studentenwerk Potsdam
Anstalt des öffentlichen Rechts

Service-Tel. 030 74 74 74 74

Um einen störungsfreien Betrieb der Geräte zu ermöglichen, sollten Sie folgendes beachten:

- Zigarettenrauch löst keinen Alarm aus, sofern der Rauch nicht vorsätzlich und direkt in den Rauchmelder gelangt.
- Die Pyrex GmbH sichert die Betriebsbereitschaft der Rauchmelder durch jährliche Wartungen ab.
- Bitte prüfen Sie bei einem Alarm des Rauchmelders, ob wirklich ein Brandherd existiert, wenn nicht schauen Sie bitte bei dem Punkt Störalarm. Bei einem Brand folgen Sie bitte umgehend den Anweisungen der Brandschutzordnung!
- Wenn die Alarmbereitschaft des Gerätes gefährdet ist, ertönt ein regelmäßig kurzer Hinweiston (Help-Signal). Im Falle dieses Signals informieren Sie bitte den Service.
- Die Rauchmelder sind nicht Ihr Eigentum. Missbräuchliche Behandlung der Geräte und daraus entstehende Service-Kosten können Ihnen in Rechnung gestellt werden.

Bitte beachten Sie, dass folgende Umgebungseinflüsse zum Störalarm führen können:

- starke Koch-, Wasser- und Branddämpfe
- große Temperaturschwankungen
- Raum-, Duft- und Insektenspray
- Blüten-, Bau-, Schleif-, und Feinstaub

Um einen Störalarm zu vermeiden, sollte das Gerät vor solchen Umgebungseinflüssen geschützt werden. Auch eine vorsichtige, regelmäßige Reinigung kann Abhilfe schaffen.



Beim Kochen in der Nähe des Rauchmelders ist auf eine gute Belüftung der Räume zu achten. Ein Störalarm ist durch sanften Druck der Stopp-Taste und durch gutes Belüften der Räume abzustellen.

Bitte achten Sie unbedingt darauf, dass die Lufteinlässe am umlaufenden Rand der Rauchmelder niemals durch Staub, Schmutz oder Klebeband etc. beeinträchtigt werden!

Achtung:

Rauchmelder unterstützen dabei, Brände frühzeitig zu bemerken, können jedoch weder ein Feuer löschen, noch die Entstehung eines Brandes verhindern und auch nicht die Feuerwehr alarmieren.

Rauchmelder geben, wenn Gefahr durch Brandgase besteht, einen lauten Alarmton ab, der Sie auf die Gefahr aufmerksam macht. Die üblichen Vorsichtsregeln im Umgang mit Feuer, brennbaren Materialien und technischen Geräten sind stets zu beachten!

Sollten Sie eine Störung des Gerätes bemerken, informieren Sie bitte umgehend den Service.

Smoke Detector Instructions Pyrex



Studentenwerk Potsdam
Anstalt des öffentlichen Rechts

Service-Hotline 030 74 74 74 74

For fault-free operation of the devices, follow these instructions:

- Cigarette smoke will not trigger an alarm, as long as the smoke is not deliberately blown directly into the smoke detector.
- Pyrex GmbH ensures the operational readiness of the smoke detectors by performing yearly maintenance.
- If the smoke detector alarm is activated, please check whether there really is a fire. In case of fire, immediately follow the instructions on the fire protection regulations!
- If there is danger that the alarm is not operational, the device emits a short tone at regular intervals (help signal). If this signal occurs, inform the service department immediately.
- The smoke detectors are not your property. You can be charged for service costs resulting from improper handling of the devices.

Please observe that the following environmental influences can lead to a false alarm:

- Excessive steam and vapors from cooking, boiling or frying
- Excessive temperature fluctuations
- Air freshener, fragrances or insect spray
- Pollen, dust from construction or sanding and fine dust

To avoid a false alarm from the smoke detector the device should be protected against such environmental influences. To help prevent false alarms it is also advisable to carefully clean the device with a vacuum cleaner at regular intervals.



While cooking near the smoke detector ventilate the rooms well. A false alarm can be turned off or prevented by gently pressing the test/stop button and ventilating the rooms well.

Please make sure that the air vents along the circumference of the smoke detector are not obstructed by dust, dirt, paint or tape!

Caution:

Smoke detectors help to spot fires early but can neither extinguish fires, prevent the start of fires nor alert the fire department.

Smoke detectors emit an alarm if there is a hazard due to fumes in order to call your attention to this hazard. Always observe standard precautions for dealing with fire, flammable materials and technical equipment!

If you notice that the device has a malfunction, inform the service department immediately.